

,

## **INSPECTION**

- a. Check the parking brake switch operation.
- b. Check the parking brake lever ratchet for wear.
- c. Check the parking brake cable for fraying or damage.